


ZONE	REV	DESCRIPTION	DATE	APPROVED


UCS HIGH SCHOOL LONG JUMP/TRIPLE JUMP TAKEOFF SYSTEM INSTALLATION INSTRUCTIONS

NOTE: A PVC drain should be supplied and installed by the contractor when installing the foundation tray.

1. Base of foundation tray should rest on a level concrete surface which is located 127mm below top of base surface and foundation tray. (fig. 1)
2. Lip of foundation tray should be flush with base surface. Check level and pour concrete around tray. (fig. 2)




(Fig. 1)



(Fig. 2)

ITEM	PT. NO.	DESCRIPTION	QTY.
2	519-B1021-00	FOUNDATION TRAY	(1)
3	519-B1021-10	BOARD UNDERSTRUCTURE	(1)
4	519-B121-10A	TAKE-OFF BOARD	(1)
5	----	ADJUSTING AND LEVELING SCREW	(6)
6	----	(3/8-16 X1 1/2) NUTS (3/8-16) FOR LEVELING SCREW	(4)
		SCREW, WOOD, FLAT HD. #6 X 1 1/2	(8)

PARTS LIST



This drawing contains information proprietary to UCS Inc., any reproduction disclosure or use of this drawing is EXPRESSLY PROHIBITED unless agreed in writing by UCS Inc.

UCS		800-526-4856		www.ucsspirit.com	
UNLESS OTHERWISE SPECIFIED		CONTRACT NO.		511 HOFFMAN RD.	
DIMENSIONS ARE IN INCHES		DRAWN: V. ANGELOV		LINCOLNTON, N.C. 28092	
SPEC. TOL. ANGLE TOL.		DATE		TITLE	
2 PLACES ±.03		CHECKED		HIGH SCHOOL	
3 PLACES ±.010		CHECKED		JUMP TAKEOFF SYSTEM	
MATERIAL:		SIZE		FILE	
PROTECTIVE FINISH:		D 519-2100		DWG NO. 519-2200	
		SCALE NONE		REV. -	
				SHEET 1 OF 1	